

# STAIR DUE


## Installation Manual

1




### Attention

Before any maintenance switch off the main power.




2




### Attention

Make sure that the screw head does not stick out of the profile.

3



4



5

